






KAWASAKI MEAN STREAK 1500 & 1600 REAR AXLE BRACKETS INSTALLED




KAWASAKI MEAN STREAK 1500 & 1600 BELLY BRACKET INSTALLED



KAWASAKI MEAN STREAK 1500 & 1600

DESCRIPTION OF PARTS



Two 2" shims– not shown in picture above.
 You may or may not have to use the shims. See note below.

After installing the mounting hardware and attaching the Voyager frame to the belly bracket you may need shims to make the motorcycle stand straight up and down. The shims will go on the front and back of the right side of the belly bracket.

Right Side Only
 Install the shims in-between belly bracket and motorcycle frame. The shims will go on top of belly bracket tabs.



ILLUSTRATION OF SHIM PLACEMENT
 BRACKET PICTURED MAY NOT MATCH YOUR BRACKET

SECTION 1

INSTALLATION OF

KAWASAKI MEAN STREAK 1500 & 1600

MOUNTING HARDWARE

Place motorcycle on a clean flat surface. Make sure to tie down motorcycle on both sides, so that motorcycle can not tip over while installing hardware. Installation is easier if motorcycle is in an upright position.

Disconnect negative cable from battery before beginning installation.

NOTE: The Voyager Convertible Kit was designed for a stock motorcycle from the manufacturer. Any after market products that are on a stock motorcycle may cause the installation process to not be done properly and may or may not need to be removed to be able to install the Voyager Convertible Kit completely. Be aware that your motorcycle and the same make & model as someone else's motorcycle may not have mufflers, body panels, frames, fenders and any other manufacturer parts that are attached to the motorcycle in the exact same place as yours. We at Motorcycle Tour Conversion, Inc. take that into consideration when we manufacture our parts to fit your motorcycle. Once in awhile you may need to modify your motorcycle slightly so that the Motorcycle Tour Conversion, Inc. hardware or suspension fits your motorcycle. Please call Motorcycle Tour Conversion, Inc. if you have any questions about installation with after market products or any modification of motorcycle and/or Motorcycle Tour Conversion, Inc. hardware.

A) BELLY BRACKET

- 1) Remove the two bolts that hold the left side floor board to the frame.
- 2) Bolt the "L" bracket to the outside of the floor board bracket. (Bolt the roll bar bracket to the outside of the "L" bracket.
- 3) Hang one of the "U" bolts over the frame behind the kickstand bracket (Approximately 5")
- 4) Hang the remaining two "U" bolts on the right side of the frame. One just behind the brake pedal and the other just in front of the frame junction. (It may be necessary to remove the tie down straps that hold the rear brake line to the frame. Remember to replace the strap after the hardware is installed.)
- 5) Attach the belly bracket to the three "U" bolts and left front "L" bracket using the bolts, flat washers, and locking nuts provided with this kit. (Do Not Tighten any of the bolts until they are all hooked up)
- 6) Now torque all of the belly bracket bolts to 20 ft. lbs.

SECTION 1
INSTALLATION OF
KAWASAKI MEAN STREAK 1500 & 1600
MOUNTING HARDWARE

B) REAR AXLE BRACKETS

- 1) Remove the saddle bags from the bike.
- 2) Remove the cotter pin, axle nut and washer.
- 3) Remove the outer/lower drive shaft housing retaining nut.
- 4) Tap the axle out approximately 3/8".
- 5) Install the left rear axle bracket front arm onto the exposed drive shaft stud and the other slot over the axle bolt between the bolt head and washer.
- 6) Replace the drive shaft housing nut and torque to 25 ft. lbs.
- 7) Place the right rear axle bracket over the axle and use the low profile castle nut (provided with kit)
- 8) Attach the front swing arm attachment to the bottom of the swing arm with the hose clamp provided with this kit.
- 9) Torque the axle nut to 70 ft. lbs. and replace the cotter pin.



MOTORCYCLE TOUR CONVERSION, INC.
1530 TITANIUM DR
OTTAWA, IL. 61350

TOLL FREE: 877-434-7901
FAX: 815-434-8980

KAWASAKI MEAN STREAK 1500 & 1600

INSTALLATION MANUAL
US PATENT # 6,739,420

**WARRANTY WILL BE VOID IF INSTALLATION
IS NOT DONE PROPERLY**

**READ THIS MANUAL FULLY BEFORE
BEGINNING INSTALLATION OR DRIVING YOUR
MOTORCYCLE WITH THE VOYAGER KIT ATTACHED**